

Dräger X-am[®] 5600

Featuring an ergonomic design and innovative infrared sensor technology, the Dräger X-am[®] 5600 is the smallest gas detection instrument for the measurement of up to 6 gases. Ideal for personal monitoring applications, this robust and water-tight detector provides accurate, reliable measurements of explosive, combustible and toxic gases and vapors as well as oxygen.



SMALL YET ROBUST

Small, light and easy to use - the robust and water-tight Dräger X-am 5600 is designed for single-handed operation in tough industrial environments. Water- and dustproof according to IP 67 and with an integrated rubber boot, the device provides optimal functionality even under harsh conditions.

DURABLE INFRARED TECHNOLOGY

Thanks to the high stability and a resistance to contamination, Dräger infrared sensors can generally be used for up to eight years. This advanced technology reduces the cost of ownership considerably because less replacement sensors are needed. In addition, a sensor calibration is only necessary every 12 months which reduces maintenance costs.

SINGLE OR DUAL SENSOR – ACCURATE MEASUREMENT RESULTS

The new Dräger infrared sensors can be used for the measurement of explosive substances or CO₂: The infrared sensor IR Ex allows the measurement of explosive, combustible hydrocarbons in the range of the lower explosive limit. With this sensor, measurements in the range of 0-100 Vol.-% for methane, propane and ethylene are also possible. The infrared sensor IR CO₂, with

a measurement resolution of 0.01 Vol.-%, provides safe and exact measurements as well as a warning against toxic concentrations of carbon dioxide in the ambient air. For those applications where the reliable measurement of explosive substances and CO₂ is specifically needed, the advantages of both can be achieved by a dual sensor (Dual IR CO₂/Ex).

ALSO IN COMBINATION WITH HYDROGEN

Besides hydrocarbons, hydrogen can also be an explosive gas. Because sensors based on infrared technology do not warn against hydrogen explosion dangers, the Dräger X-am 5600 combines two sensor signals (Infrared Ex and electrochemical H₂) for reliable hydrogen detection. The X-am 5600 provides the advantages of poison-free technology to be used in areas where, until now, only catalytic Ex sensors have been used.

VARIOUS MONITORING POSSIBILITIES

Thanks to the combination of innovative infrared technology and the latest electrochemical Dräger XXS miniature sensors, this 1-to-6 gas detector reliably detects explosive, combustible and harmful concentrations of O₂, Cl₂, CO, CO₂, H₂, H₂S, HCN, NH₃, NO, NO₂, PH₃, SO₂, Amine, Odorant, COCl₂ and organic vapors. With the PC software



Dräger X-am® 5600 Small, light and tough for single-handed detection of up to 6 gases.

Dräger CC-Vision, the sensors can easily be exchanged, calibrated or converted to meet the needs of different applications.

FLEXIBLE USE

This small gas detection instrument is perfectly suited as a personal monitor. The simple two-button control panel allows for the intuitive use of the device. The gas inlets - on the upper and front side - provide optimal measurement accuracy even if they are inadvertently placed in a pocket or a gas inlet is covered.

An optional external pump which can be operated with hoses up to 30 m or 98 ft. in length is the perfect solution for pre-entry measurements in tanks or pipelines. To monitor entire areas, the Dräger X-am 5600 can be used in combination with the innovative Dräger X-zone 5000.

SUITABLE FOR EX ZONE 0

The small and reliable gas detector is suitable for use in areas classified as zone 0, which are areas where explosive atmospheres are always to be expected.

SIMPLE SOLUTION FOR BUMP TESTS

Simple, guick, and professional: From bump testing to complete documentation, users can choose from a range of practical, on-site solutions for optimal safety in every application. Both the Dräger E-Cal automatic test and calibration station and the Dräger Bump Test Station are ideal system extensions that save costs and time.



ORDER INFORMATION

Dräger X-am 5600				83 21 050
Consisting of: basic instrument with an	integrated data logger, support CD, manufacturer's a	and calibration certificates.		
A functional instrument must include up	to 4 sensors and a power supply unit.			
			Response	
Infrared-Sensors	Measuring Range	Resolution	time (t ₉₀)	Order code
DrägerSensor Dual IR Ex/CO ₂ ¹)	0 - 100 % LEL	1 % LEL	20 sec.	68 11 960
	0 - 100 Vol% Methane, Propane, Ethylene	0.1 Vol% CH ₄		
	0 - 5 Vol% CO ₂	0.01 Vol% CO ₂		
DrägerSensor IR Ex ¹⁾	0 - 100 % LEL	1 % LEL	20 sec.	68 12 180
	0 - 100 Vol% Methane, Propane, Ethylene	0.1 Vol% CH ₄		
DrägerSensor IR CO ₂	0 – 5 Vol% CO ₂	0.01 Vol% CO ₂	20 sec.	68 12 190

ORDER INFORMATION

Electrochemical Sensors	Measuring Range	Resolution	Response time (190)	Order Code
DrägerSensor XXS O ₂	0 – 25 Vol%	0.1 Vol%	10 sec.	68 10 881
DrägerSensor XXS CO	<u>0 – 2,000 ppm</u>	2 ppm	15 sec.	68 10 882
DrägerSensor XXS CO HC	0 - 10,000 ppm	5 ppm	25 sec.	68 12 010
DrägerSensor XXS CO/H ₂ compensated	0 - 2,000 ppm CO	2 ppm	25 sec.	68 11 950
DrägerSensor XXS H ₂ S	0 – 200 ppm	1 ppm	<u>15 sec.</u>	68 10 883
DrägerSensor XXS H ₂ S LC	0 – 100 ppm	0.1 ppm	<u>15 sec.</u>	68 11 525
DrägerSensor XXS H ₂ S HC	<u>0 – 1,000 ppm</u>	2 ppm	15 sec.	68 12 015
DrägerSensor XXS CO/H₂S	0 - 2,000 ppm CO / 0 - 200 ppm H ₂ S	1 ppm H ₂ S / 2 ppm CO	<u>20 sec.</u>	68 11 410
DrägerSensor XXS NO	0 – 200 ppm	0.1 ppm	<u>10 sec.</u>	68 11 545
DrägerSensor XXS NO ₂	0 – 50 ppm	0.1 ppm	<u>15 sec.</u>	68 10 884
DrägerSensor XXS SO ₂	<u>0 – 100 ppm</u>	0.1 ppm	<u>15 sec.</u>	68 10 885
DrägerSensor XXS PH ₃	0 – 20 ppm	0.01 ppm	<u>10 sec.</u>	68 10 886
DrägerSensor XXS PH ₃ HC	<u>0 – 2,000 ppm</u>	1 ppm	10 sec.	68 12 020
DrägerSensor XXS HCN	<u>0 – 50 ppm</u>	0.1 ppm	10 sec. (t ₅₀)	68 10 887
DrägerSensor XXS NH ₃	<u>0 – 300 ppm</u>	1 ppm	20 sec. (t ₅₀)	68 10 888
DrägerSensor XXS CO ₂	<u>0 – 5 Vol%</u>	0.1 Vol%	30 sec. (t ₅₀)	68 10 889
DrägerSensor XXS Cl ₂	0 – 20 ppm	0.05 ppm	30 sec.	68 10 890
DrägerSensor XXS H ₂	<u>0 – 2,000 ppm</u>	5 ppm	10 sec.	68 12 370
DrägerSensor XXS H ₂ HC	0 – 4 Vol%	0.01 Vol%	20 sec.	68 12 025
DrägerSensor XXS OV	<u>0 – 200 ppm</u>	0.5 ppm	20 sec. (t ₅₀)	68 11 530
DrägerSensor XXS OV-A	0 – 200 ppm	1 ppm	40 sec. (t ₅₀)	68 11 535
DrägerSensor XXS Amine	0 – 100 ppm	1 ppm	30 sec.	68 12 545
DrägerSensor XXS Odorant	0 – 40 ppm	0.5 ppm	90 sec.	68 12 535
DrägerSensor XXS COCl ₂	0 – 10 ppm	0.01 ppm	30 sec.	68 12 005
Electrochemical Sensors with 5 years warr	antv			
DrägerSensor XXS E CO	0 – 2,000 ppm	2 ppm	15 sec.	68 12 212
DrägerSensor XXS E H ₂ S	0 – 200 ppm	1 ppm	15 sec.	68 12 213
DrägerSensor XXS E O ₂	0 – 25 Vol%	0.1 Vol%	10 sec.	68 12 211
1) Special calibration for Ex sensors are available (standa	_	0.1 ¥01. 70	10 300.	00 12 211
Power supply units				
NiMH power pack T4				83 18 704
NiMH power pack T4 high capacity				83 22 244
Power pack & charging set consisting of: rec	hargeable NiMH power supply T4, charging m	nodule and a single charger (for	worldwide use)	83 18 785
Alkaline power pack T3/T4 (without alkaline b	patteries)			83 22 237
Alkaline batteries T4 (2 pcs.) for alkaline pow	ver supply 83 22 237			83 22 239
NiMH rechargeable batteries T3 for alkaline p	oower supply unit 83 18 703, charged external	у		83 19 426
Charging accessories				
Charging accessories Charging module				83 18 639
	ng module and a single power supply (worldw	ida usa)		83 20 333
Power supply with connection cable (worldwing)	0 1 1171	ide use)		83 15 805
Single charger (worldwide use) for max. 5 ch				83 16 994
Single charger (worldwide use) for max. 2 ch	-			
Car charging connection cabel 12V/24 V for a	<u> </u>			83 15 635 45 30 057
Vehicle charger mounting kit for one Dräger 2				83 18 779
Tomore sharger meaning his for one Brager.	A can occo onarging module			
Pump accessories				
Dräger X-am 1/2/5x00 external pump				83 19 400
Hand pump adapter				83 19 195
Confined space entry set, with an external pu	imp and 3 m or 9 ft. viton hose			83 19 399
Carrying case Dräger X-am 1/2/5x00 external	pump (without pump)			83 19 385
0.11				
Calibration accessories				00 10 750
Calibration cradle				83 18 752
Dräger E-Cal module for Dräger X-am 5600	600 and including any Park			83 18 754
Dräger Bump Test Station for Dräger X-am 5				83 19 131
Dräger Bump Test Station for Dräger X-am 50 with one test gas cylinder 58L (gas and cond	•			83 19 130
Printerset for Dräger Bump Test Station cons	· · · · · · · · · · · · · · · · · · ·			83 21 011
single charger, rechargeable NiMH batteries,				00 21 011
Nonane Checker				
				83 20 080

Communication accessories	
Dräger GasVision	83 14 034
Dräger CC-Vision	64 08 515
USB DIRA with USB cable, communication adapter infrared to USB	
PC communication set 1 with USB port, Dräger CC-Vision incl. registration software	
PC communication set 2 with USB port, Dräger CC-Vision incl. registration software and barcode reader	
System components	_
Dräger X-zone 5000 - 868 MHz, 12 Ah	83 20 740
Dräger X-zone 5000 - 868 MHz, 24 Ah	83 20 741
Dräger X-zone 5000 - 868 MHz1 12 Ah with pump	83 20 742
Dräger X-zone 5000 - 868 MHz, 24 Ah with pump	
In conjunction with the portable alarm amplifier Dräger X-zone 5000 the units are combined to a new system; to monitor whole working areas	

TECHNICAL DATA

or to connect to external alarm contacts.

Dimensions (W x H x D)	47 x 130 x 44 mm;	47 x 130 x 44 mm; 1.85 x 5.12 x 1.73 inches		
Weight	250 g; 8.8 oz.			
Ambient conditions	Temperature	-20 to +50 °C; -4 to +122 °F		
	Pressure	700 to 1300 mbar; 20.7 to 38.4 inch Hg		
	Humidity	10 to 95% RH		
Alarms	Visual	360°		
	Audible	Multi-tone > 90 dB at 30 cm; 1 ft.		
	Vibration			
Ingress Protection	IP 67			
Operating time	~10 h or rather ~12	~10 h or rather ~12 h		
Charging time	< 4 hours	< 4 hours		
Data logger	Can be read out vi	Can be read out via Infrared > 1000 hours		
	with 6 gases and a	with 6 gases and a recording interval of 1 value per minute		
Pump operation	Maximum hose len	Maximum hose length 30 m; 98 ft.		
Approvals	ATEX	I M1 Ex ia I Ma		
		II 1G Ex ia IIC T4/T3 Ga		
	IEC	Ex ia I Ma		
		Ex ia IIC T4/T3 Ga for MQG 01**		
	MED	⊗ (0736-YY)		
	UL	(pending)		
	CSA	(pending)		

HEADQUARTERS

Dräger Safety AG & Co. KGaA Revalstrasse 1 23560 Lübeck, Germany

www.draeger.com

SUBSIDIARIES

AUSTRALIA

Draeger Safety Pacific Pty. Ltd. Axxess Corporate Park Unit 99, 45 Gilby Road Mt. Waverley Vic 3149 Tel +61 3 92 65 50 00 Fax +61 3 92 65 50 95

CANADA

Draeger Safety Canada Ltd. 7555 Danbro Crescent Mississauga, Ontario L5N 6P9 Tel +1 905 821 8988 Fax +1 905 821 2565

P. R. CHINA

Beijing Fortune Draeger Safety Equipment Co., Ltd. A22 Yu An Rd, B Area, Tianzhu Airport Industrial Zone, Shunyi District, Beijing 101300 Tel +86 10 80 49 80 00 Fax +86 10 80 49 80 05

FRANCE

Dräger Safety France SAS 3c route de la Fédération, BP 80141 67025 Strasbourg Cedex 1 Tel +33 3 88 40 59 29 Fax +33 3 88 40 76 67

MEXICO

Draeger Safety S.A. de C.V. Av. Peñuelas No. 5 Bodega No. 37 Fraccionamiento Industrial San Pedrito Querétaro, Qro México Tel +52 442 246-1113 Fax +52 442 246-1114

NETHERLANDS

Dräger Safety Nederland B.V. Edisonstraat 53 2700 AH Zoetermeer Tel +31 79 344 46 66 Fax +31 79 344 47 90

REP. OF SOUTH AFRICA

Dräger South Africa (Pty) Ltd. P.O.Box 68601 Bryanston 2021 Tel +27 11 465 99 59 Fax +27 11 465 69 53

SINGAPORE

Draeger Safety Asia Pte Ltd 67 Ayer Rajah Crescent #06-03 Singapore 139950 Tel +65 68 72 92 88 Fax +65 65 12 19 08

SPAIN

Dräger Safety Hispania S.A. Calle Xaudaró 5 28034 Madrid Tel +34 91 728 34 00 Fax +34 91 729 48 99

UNITED KINGDOM

Draeger Safety UK Ltd.
Blyth Riverside Business Park
Blyth, Northumberland
NE24 4RG
Tel +44 1670 352-891
Fax +44 1670 356-266

USA

Draeger Safety, Inc. 101 Technology Drive Pittsburgh, PA 15275 Tel +1 412 787 8383 Fax +1 412 787 2207